


Instruction Manual Smart Curtain Module

WiFi

MMC1982



English



Bitte lesen Sie den QR-Code, um das Installationsvideo und die Funktionseinführung zu erhalten

• Escanee el código QR para obtener el manual en español, el video de instalación y la introducción de la función

• Veuillez scanner le code QR pour obtenir le manuel en français, la vidéo d'installation et l'introduction des fonctions

• Отсканируйте QR-код, чтобы получить руководство на русском языке, видео по установке и описание функций

• Scansionare il codice QR per ottenere il manuale in italiano, il video di installazione e la guida alle funzionalità. Video di installazione e funzionalità


• Zeskanuj kod QR, aby uzyskać instrukcje, filmy instalacyjne i funkcje

• من فضلك قم بمسح رمز الاستجابة السريعة (QR-code) للحصول على دليل المستخدم باللغة العربية وفيديو التثبيت ووصف الوظائف




请扫描二维码获取中文的说明书、安装视频及功能介绍

Global international operation Whenever & Wherever You are, All-in-one Mobile App



Inhouse local operation




Step 1

- Turn off the circuit breaker and use the electrical tester to test the power.
- Ensure the switch is off before wiring.



Step 2

- Remove the old switch



Step 3

Remove the switch and pull it away from the wall. Identify Line/Load Wire (Note: The color of your wire may be different from the color shown on the manual.)


⚠ Verify power is off

- We recommend you remove the faceplate from the old switch and use an electrical tester to test all wires connected to the switch to ensure there is no voltage in the circuit.
- You may need to turn off more than one circuit breaker.

INSTALLATION

⚠ Warnings:



1. Installation must be carried out by a qualified electrician in accordance with local regulations.
2. Keep the device out of the reach of children.
3. Keep the device away from water, damp or hot environment.
4. Install the device away from strong signal sources such as microwave oven that may cause signal interruption resulted in abnormal operation of the device.
5. Obstruction by concrete wall or metallic materials may reduce the effective operation range of the device and should be avoided.
6. Do NOT attempt to disassemble, repair or modify the device.



TECHNICAL SPECIFICATIONS

Model	MS-108B
Product type	2 Gang Smart Curtain Module
Voltage	90-250V AC 50/60Hz
Max current	2A
Wireless protocol	Wi-Fi 2.4GHz
Operation temp.	-10°C - +40°C
Case temp.	Tc: +80°C (Max.)
Dims (WxDxH)	52x47x22.5 mm
IP rating	IP20

WIRING DIAGRAM



Wiring Instructions and Diagrams

1. Turn off the power supply before carrying out any electrical installation work.
2. Connect wires according to the wiring diagram.
3. Insert the module into the junction box.
4. Connect the power supply and follow switch module configuration instructions.

Note: Put your smartphone close to the switch module when you're configuring, and make sure you have min. 50% Wi-Fi signal.

Preparation For Use


1. Download MOES App on App store or scan the QR code



MOES App is upgraded as much more compatibility than Tuya Smart/Smart Life App, functional well for scene controlled by Siri, widget and scene recommendations as the fully new customized service. **(Note: Tuya Smart/Smart Life App still works, but MOES App is highly recommended)**


2 Registration or Log in.

- Download "MOES" Application.
- Enter the Register/Login interface; tap "Register" to create an account by entering your phone number to get verification code and "Set password". Choose "Log in" if you already have a MOES account.



3 Wi-Fi link method: (two pairing methods)

- 3.1 Method one: Scan the QR code to configure the network guide.




Scan the QR code



Please connect the device according to the configuration process.


How to reset Wi-Fi code

- a. For switch module:** long press the reset button on the module until you hear the beep sounds continuously and rapidly as Di-Di-Di...
- b. For reset light switch:** press the switch button for 10 times until the beep sounds continuously and rapidly as Di-Di-Di... for pairing and reset mode.



3.2 Method two: Pair with traditional pairing method.

1. Confirm the device beeps continuously.



2. Open the App, select "+" on top right and choose "Switch (Wi-Fi)" to add device.