

Matter Wi-Fi

Instruction Manual Smart Switch

Matter Wi-Fi

English

QRコードをスキャンして、日本語のマニュアル、インストールビデオ、機能紹介を入手してください。
QRコードを 스캔하여 한국어, 영어, 중국어 설명서와 비디오, 기능 소개를 받으십시오.
اسكن الرمز الاستجابة للحصول على دليل المستخدم باللغة العربية، الفيديو التعليمي، ومعلومات الميزات.

Technical Parameters:
Model: WS-EU / WS-US
Voltage: 90-250V AC, 50/60Hz
Frequency: 10A / 15A, Total 10A
Wireless Protocol: Matter Wi-Fi, 2.4GHz
Frequency Band: 2.412, 2.424, 2.436GHz
Maximum Radio Transmit Power: ≤ 100mW

Safety Information:
Risk of Electric Shock: Electricity can cause personal injury and property damage. If handled improperly if you are not sure about any part of these instructions, please seek professional assistance from a qualified electrician.

Installation:
1. Turn off the circuit breaker and use the electrical tester to test the power.
2. Remove the old switch.
3. Remove the switch and pull it away from the wall. Identify Line, Load, and Wire/Nerve. The color of your wire may be different from the color shown on the manual.
4. Verify power is off.
5. Remove the panel with screwdriver.
6. Prepare to install wiring.
7. Connect the switch to the circuit.
8. Turn on the power and test the device.

Preparation for use:
1. Download MOES App on App store or scan the QR code.
2. Register an account.
3. Add the device to the app.
4. Connect the device to the Wi-Fi network.

Steps for connecting the APP to the device:
1. Turn on the power and hold the button for about 6 seconds until the indicator on the switch flashes twice and a sound is heard. The device has entered the pairing mode.
2. Press and hold the button for about 6 seconds until the indicator on the switch flashes twice and a sound is heard. The device has entered the pairing mode.

Control your home with your voice

CE declaration of conformity

Warranty Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying FCC exposure compliance. This transmitter will not be co-located or installed in conjunction with any other antenna or transmitter.

WARRANTY INFORMATION:
Dear Sir or Madam, thank you for purchasing the product. We hope you'll enjoy using it.
The warranty for the products in the warranty card is hereby granted as follows:
As a condition of using the warranty, you must comply with the following terms and procedures:
1. Products are covered by a 24-month warranty, effective from the date of purchase of the covered product for help.
2. In order to exercise warranty rights, the purchaser must present a Warranty card & Proof of purchase (VAT receipt, financial receipt or other document confirming the actual date of purchase), unless the purchase date of the product comes from the warranty card.
3. If product quality problems occur within 24 months from the date of receipt, please prepare the product and packaging and go to the place or store where you purchased it to apply for after-sales maintenance. If the equipment is damaged due to personal reasons, a certain maintenance fee will be charged.
4. Damage caused by improper use of the product. I.e. The rights under the guarantee will expire in the following cases:
a) Failure to follow the instructions for use.
b) Removal of the warranty seal from the product.
c) Removal of the serial number from the product.
d) Failure to follow the instructions for use in the product document or authorized service.
e) Use of non-original parts and components.
f) Modification of the product without the manufacturer's approval.
g) Alteration of the product without the manufacturer's approval.
h) Use of the product for purposes other than those specified in the product document or authorized service.
i) Failure to follow the instructions for use in the product document or authorized service.
j) Failure to follow the instructions for use in the product document or authorized service.
k) Failure to follow the instructions for use in the product document or authorized service.
l) Failure to follow the instructions for use in the product document or authorized service.
m) Failure to follow the instructions for use in the product document or authorized service.
n) Failure to follow the instructions for use in the product document or authorized service.
o) Failure to follow the instructions for use in the product document or authorized service.
p) Failure to follow the instructions for use in the product document or authorized service.
q) Failure to follow the instructions for use in the product document or authorized service.
r) Failure to follow the instructions for use in the product document or authorized service.
s) Failure to follow the instructions for use in the product document or authorized service.
t) Failure to follow the instructions for use in the product document or authorized service.
u) Failure to follow the instructions for use in the product document or authorized service.
v) Failure to follow the instructions for use in the product document or authorized service.
w) Failure to follow the instructions for use in the product document or authorized service.
x) Failure to follow the instructions for use in the product document or authorized service.
y) Failure to follow the instructions for use in the product document or authorized service.
z) Failure to follow the instructions for use in the product document or authorized service.

Gebruiksaanwijzing (Deutsch)

Einhrichtung

Achtung:

Sicherheitshinweise:

Technische Parameter:

Wartungsinformationen:

WARRANTY INFORMATION (English):

1. Turn off the circuit breaker and use the electrical tester to test the power.
2. Remove the old switch.
3. Remove the switch and pull it away from the wall. Identify Line, Load, and Wire/Nerve. The color of your wire may be different from the color shown on the manual.
4. Verify power is off.
5. Remove the panel with screwdriver.
6. Prepare to install wiring.
7. Connect the switch to the circuit.
8. Turn on the power and test the device.

1. Turn on the power and hold the button for about 6 seconds until the indicator on the switch flashes twice and a sound is heard. The device has entered the pairing mode.
2. Press and hold the button for about 6 seconds until the indicator on the switch flashes twice and a sound is heard. The device has entered the pairing mode.

Manual de instrucciones (Español)

Instalación

Atención:

Preparación para utilizar el dispositivo:

WARRANTY INFORMATION (English):

1. Turn off the circuit breaker and use the electrical tester to test the power.
2. Remove the old switch.
3. Remove the switch and pull it away from the wall. Identify Line, Load, and Wire/Nerve. The color of your wire may be different from the color shown on the manual.
4. Verify power is off.
5. Remove the panel with screwdriver.
6. Prepare to install wiring.
7. Connect the switch to the circuit.
8. Turn on the power and test the device.

1. Turn on the power and hold the button for about 6 seconds until the indicator on the switch flashes twice and a sound is heard. The device has entered the pairing mode.
2. Press and hold the button for about 6 seconds until the indicator on the switch flashes twice and a sound is heard. The device has entered the pairing mode.

Manuel d'instruction (Français)

Installation

Attention:

Préparation pour utiliser l'appareil:

WARRANTY INFORMATION (English):

1. Turn off the circuit breaker and use the electrical tester to test the power.
2. Remove the old switch.
3. Remove the switch and pull it away from the wall. Identify Line, Load, and Wire/Nerve. The color of your wire may be different from the color shown on the manual.
4. Verify power is off.
5. Remove the panel with screwdriver.
6. Prepare to install wiring.
7. Connect the switch to the circuit.
8. Turn on the power and test the device.

1. Turn on the power and hold the button for about 6 seconds until the indicator on the switch flashes twice and a sound is heard. The device has entered the pairing mode.
2. Press and hold the button for about 6 seconds until the indicator on the switch flashes twice and a sound is heard. The device has entered the pairing mode.

Manuale di istruzioni (Italiano)

Installazione

Attenzione:

Preparazione all'uso:

WARRANTY INFORMATION (English):

1. Turn off the circuit breaker and use the electrical tester to test the power.
2. Remove the old switch.
3. Remove the switch and pull it away from the wall. Identify Line, Load, and Wire/Nerve. The color of your wire may be different from the color shown on the manual.
4. Verify power is off.
5. Remove the panel with screwdriver.
6. Prepare to install wiring.
7. Connect the switch to the circuit.
8. Turn on the power and test the device.

1. Turn on the power and hold the button for about 6 seconds until the indicator on the switch flashes twice and a sound is heard. The device has entered the pairing mode.
2. Press and hold the button for about 6 seconds until the indicator on the switch flashes twice and a sound is heard. The device has entered the pairing mode.

Manual de Instruções (Portugues)

Instalação

Atenção:

Preparação para utilização:

WARRANTY INFORMATION (English):

1. Turn off the circuit breaker and use the electrical tester to test the power.
2. Remove the old switch.
3. Remove the switch and pull it away from the wall. Identify Line, Load, and Wire/Nerve. The color of your wire may be different from the color shown on the manual.
4. Verify power is off.
5. Remove the panel with screwdriver.
6. Prepare to install wiring.
7. Connect the switch to the circuit.
8. Turn on the power and test the device.

1. Turn on the power and hold the button for about 6 seconds until the indicator on the switch flashes twice and a sound is heard. The device has entered the pairing mode.
2. Press and hold the button for about 6 seconds until the indicator on the switch flashes twice and a sound is heard. The device has entered the pairing mode.

Руководство по эксплуатации (Русский язык)

Установка

Внимание:

Подготовка к использованию:

WARRANTY INFORMATION (English):

1. Turn off the circuit breaker and use the electrical tester to test the power.
2. Remove the old switch.
3. Remove the switch and pull it away from the wall. Identify Line, Load, and Wire/Nerve. The color of your wire may be different from the color shown on the manual.
4. Verify power is off.
5. Remove the panel with screwdriver.
6. Prepare to install wiring.
7. Connect the switch to the circuit.
8. Turn on the power and test the device.

1. Turn on the power and hold the button for about 6 seconds until the indicator on the switch flashes twice and a sound is heard. The device has entered the pairing mode.
2. Press and hold the button for about 6 seconds until the indicator on the switch flashes twice and a sound is heard. The device has entered the pairing mode.

Instrukcje użytkownika (Polski)

Instalacja

Uwaga:

Przygotowanie do użycia:

WARRANTY INFORMATION (English):

1. Turn off the circuit breaker and use the electrical tester to test the power.
2. Remove the old switch.
3. Remove the switch and pull it away from the wall. Identify Line, Load, and Wire/Nerve. The color of your wire may be different from the color shown on the manual.
4. Verify power is off.
5. Remove the panel with screwdriver.
6. Prepare to install wiring.
7. Connect the switch to the circuit.
8. Turn on the power and test the device.

1. Turn on the power and hold the button for about 6 seconds until the indicator on the switch flashes twice and a sound is heard. The device has entered the pairing mode.
2. Press and hold the button for about 6 seconds until the indicator on the switch flashes twice and a sound is heard. The device has entered the pairing mode.